

# **MECHANICAL**

#### 3390 SERIES GROUP 2M LOCK

# INSTALLATION INSTRUCTIONS Read quide completely before beginning installation.

### SAFEGUARDS FOR MOUNTING

Complete all welds to the safe prior to installation of the lock.

- Keep metal dust, filings, etc. away from the lock.
   Never oil, grease, lubricate or paint the lock.
- If applicable, keep cables away from sharp edges and moving parts.
   If applicable, never carry the lock by the cable.

### Group 2M Mechanical Lock (3390 Series) Hardware Pack, US (P/N 704004) Includes

- Spline Key (P/N 1712)
   Mounting Screws (P/N 2930 Qtv. 2)
- Mounting Screws (P/N 2930
   Mounting Screw (P/N 1819)
- Change Key (P/N 1307)
   Insert Cover (P/N 705002)
- Hardware Pack, Metric (P/N 704003) Includes
- 2. Spline Key (P/N 1712) 3. Mounting Screws (P/N 705006 - Oty 2)
- Mounting Screws (P/N 705006 Qty.
   Mounting Screw (P/N 205014)
- 5. Change Key (P/N 1307)
- 6. Insert Cover (P/N 705002)



1. If required, locate, and and tap the two holes to mount dist ring, the spindle hole, and three holes to mount the lock assembly to the inside of the safe door, Use the installation template (P/N 740.118) available on-line at wave kaibu-mas.com. 2. Attach the lock assembly to the door using the three US mounting screws provided.

Tighten the mounting screws to a torque setting of 30 inulibs, (3.4 N°m), Insert short mounting screws into the hole with marking (Figure 6). This screw is not removed during servicing of the lock.

NOTE: Ensure the lock assembly spindle hole is properly aligned with the spindle through hole in the safe door.

3. Measure total mounting thickness (door thickness + mounting plate) (Floure 2).

4. Out the spindle to a length of 1.875° (28 min) plus the total mounting stem) grigure 2).
4. Out the spindle to a length of 1.875° (28 min) plus the total mounting thickness.
5. Mount the dist ring centered on the through hole, and statch to the safe door using the two mounting screws supplied with the dial assembly. The opening index reference mark must be in the twelve of locks costition (Figure 3).

NOTE it is recommended that the lock bot errain in the related position throughout the installation procedure, to prevent inferences by the obstance during installation. See more this leep one finger over the bott while mounting the lock and installing the springle, if the bott related at any port during the installation procedure, the for this type restancist of by following the Relateding the Lock Bott instructions on page team.

(clockwise) the spindle into the drive carn until tight. Next, rotate (counterclockwise) at least 1/2 turn until the groove in the spindle is aligned with the correct spline position. (Refer to the Spine Key Position Chart - Figure 4).

Spline Key Position Chart - Figure 4).

7. Insert the spline key fully by tapping into place with a screwdriver using insertion notch

(Figure 5).

Install Cover Insert (P/N 705002), Figure 8. Press the insert into the cover using even pressure. The insert is designed to prevent spline key movement. Once installed do not attempt to remove the insert. Benove the back cover to service the look; this will not void the.







Figure 3

#### SPLINE KEY POSITION CHART

The lock risky be mounted in four positions - align the spindle groove with the corresponding cam position. The positions are marked as follows:

#### RH (right hand)

Lock bolt points right as you face the back of the door.

LH (left hand)

Lock bolt points left as you face the back to the door.

VU (vertical up) Lock bolt points upward.

VD (vertical down)
Lock bolt points downward.

## LA GARD mechanical locks are shipped with the factory combination of 50. To open:

Turn dial to the LEFT (counter-clockwise) passing 50 at least four times.
 Stop when 50 lines-up with the Opening Index (Figure 3).

 Turn RIGHT (clockwise) until dial stops, this will retract the bolt.
 (This may vary slightly by one or two numbers either up or down due to variations in alignment of dial ring during installation.)

NOTE: If using the VisionGard Dial (2085 or 2090 Series) and a lock with the factory combination, then the lock will open on 47.



in the retracted position. If the bolt becomes extended during the installation process, it can be retracted before splining the lock.

#### To retract the bolt:

While viewing the back of the lock, insert a small flat object, such as a screwdriver, into the spline notches in the cam in order to instale.
 Rotate the cam to the right (clockwise) at least 4 complete revolutions.

(Figure 7). (Mechanical tolerance +/- the width of the case

alignment mark.)

4. Rotate the cam to the left (counterclockwise) until the bolt is retracted (approximately 1/2 turn).

5. Holding the bott in the retracted position, the spindle can now be

threaded into the cam without the cam rotating. Insert the spline key using the spline key position chart.

#### Design Parameters for 3390 Series Locks

Bolt dimensions (nominal): .312 inches x 1.000 inches/8 x 25.4mm
 Bolt dimensions (nominal): .355 inches/9.0mm
 Bolt extension: .485 inches/12.3m

4. The spiride hole diameter can be a minimum of 4,96" (10.3mm) to a maximum of 4,38" (U.1mm). The 4,06" (10.3mm) diameter is recommended. Spinide hole must be obtained.
5. The lock mounting screes (14-20 or M6) require tapped holes; the recommend depth is .375" (8.83 mm), but a minimum depth of 250" (8.53 mm) is required.

6. When mounting the lock unit (i.e., integrating it in a bothwork), make sure that the lock bolt has clearance to freely move to its end positions and that the shifting force works only in the axial direction (direction of movement), Lateral forces should not be exerted on the lock.
Maximum load movable by the holt: 5 lbs. (27M)

NOTE: 3390 dead boil lock may not open if more than 5 ibs. (22N) of force is applied to the end or side of the bolt.

8. Maximum load against bolt when thrown (all directions): 224.8 lbs. (1kN)

8. Maximum load against both when thrown (all directions): 224.8 [bs.; (18N)].
9. If other parts of the bollwork are to be connected to the lock will (i.g., for activating a blocking device), corresponding adapters can be fixed with screws (#10-32 or M4) to the front of the lock both (tightening torque for "Smith screwing depth: 200Ncm maximum).
10. The lock can be fitted to safe or vault doors of any material.








Figure 8